

Installation Instructions
PART# A.5.10.1000, A.5.10.1010, A.5.10.1020,
A.5.10.1030, A.5.10.1040, A.5.10.1050, A.5.10.2200

Thank you for purchasing an ATI product!



Buffer Tube Installation

Point the rifle in a safe direction and place the safety in the "on" position. Next remove the magazine, pull back the bolt, and carefully inspect the chamber to be sure the rifle is unloaded.

Step #1

First, use an AR wrench to loosen the castle nut, making sure the teeth are facing to the rear of the weapon.



Figure 1

Step #2

Loosen the castle nut towards the rear, and slide the castle nut and the lock plate towards the rear.

Note: Notice the takedown spring after loosening the lock plate, make sure the spring stays in place.



Figure 2

Step #3

Twist the buttstock up slightly, and remove the takedown spring from the weapon. Place the spring in a safe location for later installation.



Figure 3

Step #4

Remove the takedown pin from the AR-15 and lift the upper receiver up from the rear.



Figure 4

Advanced Technology International • Made In the USA • Lifetime Warranty

2733 West Carmen Ave • Milwaukee, WI 53209 Toll Free: 800 925 2522 • Fax: 414 464 3112

www. ATIgunstocks.com



Installation Instructions

PART# A.5.10.1000, A.5.10.1010, A.5.10.1020, A.5.10.1030, A.5.10.1040, A.5.10.1050, A.5.10.2200

Thank you for purchasing an ATI product!

INTERNATIONAL

Buffer Tube Installation

Step #5

Locate the buffer retainer and the buffer retaining spring (Shown with arrow below). Push the retainer down firmly. While holding the retainer firmly down in place, begin to unscrew the buffer tube from the lower receiver.

Note: Once you have removed the buffer tube, be sure to slowly release and remove the buffer retainer and buffer retaining spring.



Figure 5

Step #6

Remove the entire buffer tube from the lower receiver.



Figure 6

Step #7

Remove the existing castle nut, lock plate, action spring, buffer tube, and buffer assembly from the AR-15 buttstock.



Figure 7

Step #8

Insert ATI buffer tube into the buttstock.



Figure 8

Step #9

Assemble the action spring and buffer assembly by securing buffer assembly tightly inside the action spring.



Figure 9

Advanced Technology International • Made In the USA • Lifetime Warranty

2733 West Carmen Ave • Milwaukee, WI 53209 Toll Free: 800.925.2522 • Fax: 414.464.3112



Installation Instructions

PART# A.5.10.1000, A.5.10.1010, A.5.10.1020, A.5.10.1030, A.5.10.1040, A.5.10.1050, A.5.10.2200

Thank you for purchasing an ATI product!

Buffer Tube Installation

Step #10

Locate the ATI castle nut and lock plate. Screw the castle nut onto the buffer tube with teeth facing the rear. Align the lock plate with existing notch on buffer tube (shown in figure 10). Slide the lock plate towards the rear against the castle nut.

INTERNATIONAL



Figure 10

Step #11

Locate the takedown spring. Align and insert the spring back into place. Next, thread the buffer tube attached to the buttstock into place on the lower receiver.

Note: Before tightening the castle nut, be sure to align the lock plate to the lower receiver with takedown spring securely in place.



Figure 11

Step #12

Continue to secure the buffer tube into the lower receiver until it is locked in place and secure with the buffer retainer.

Note: A notch on the buffer tube will allow you to secure the buffer tube in place with the buffer retainer.



Figure 10

Step #13

Insert the action spring and buffer assembly into the buffer tube to the rear. Firmly push the assembly into buffer tube so that the head of the assembly is facing the front of the weapon.

Note: Holding the buffer retainer down with your finger or a screwdriver will help the assembly to slide into place.



Figure 13

Advanced Technology International • Made In the USA • Lifetime Warranty

2733 West Carmen Ave • Milwaukee, WI 53209 Toll Free: 800.925.2522 • Fax: 414.464.3112



Installation Instructions
PART# A.5.10.1000, A.5.10.1010, A.5.10.1020,
A.5.10.1030, A.5.10.1040, A.5.10.1050, A.5.10.2200

Thank you for purchasing an ATI product!

Buffer Tube Installation

Step #14

Firmly push the action spring and buffer assembly into place so that the buffer retainer is holding the assembly in a spring loaded position.

Note: Make sure the buffer retainer, buffer retaining spring, takedown spring, and lock plate are correctly aligned and in place before moving to step 15.



Figure 14

Step #15

Bring the upper receiver back down into place towards the rear. Insert the takedown pin back into the lower receiver of the AR-15, and lock in place.



Figure 15

Step #16

Use an AR wrench to tightly secure the castle nut and buffer tube in place.



Figure 16

Step #17

You have now successfully installed ATI's AR-15 military aluminum buffer tube package. Enjoy!



Figure 16

Advanced Technology International • Made In the USA • Lifetime Warranty

2733 West Carmen Ave • Milwaukee, WI 53209 Toll Free: 800.925.2522 • Fax: 414.464.3112