



INSTALLATION INSTRUCTIONS

PART No.

FB33193F

2018 – Current JL Wrangler

Aluminum Black Powder Coated Front Inner Fenders



FRONT



REQUIRED TOOLS

3mm Allen
Drill
9/32" Drill Bit
(2) 8mm Wrenches
10mm Socket

RECOMMENDED TOOLS

M5 Nutsert Tool

KIT CONTAINS

Front Inner Fender Set (Driver/Passenger)

QTY

1
1

Front Set:

15mm Washer
10mm Washer
M5 Nutsert
20mm Button Head Bolt
16mm Button Head Bolt
M5 Serrated Nut

4
4
2
2
4
4



INSTALLATION INSTRUCTIONS

PART No.

FB33193F

2018 – Current JL Wrangler

Aluminum Black Powder Coated Front Inner Fenders

1) PREPARE YOUR VEHICLE

Remove your vehicle's existing inner and outer fenders. Please visit Fishbone Offroad on YouTube for instructions on how to remove your OEM parts.



Within the driver and passenger **front** wells, and with a 9/32" drill bit, you will need to mark and drill a hole to install the supplied nutserts with either an M5 Nutsert tool, or (2) 8mm Wrenches.



2) INSTALL YOUR FRONT FENDERS

Note: The mesh and accent plates can be removed with a 3mm Allen key to be painted separately.

Slide your front inner fenders into the well and align the holes behind the body and into the nutsert. With a 3mm Allen key secure your fenders to the body with the included hardware.



Tighten all visible bolts with a 3mm Allen key.

Repeat on the opposite side.

3) ENJOY YOUR NEW FISHBONE OFFROAD ALUMINUM INNER FENDERS!