

SM-8564

Installation Instructions

BRITISH SMLE MKI #4 & #5 SCOPE MOUNT

(Fits British .303 guns with flat side receiver and peep sight on rear of same)

BE SURE GUN IS NOT LOADED

1. Remove gun's rear sight pin (drive pin's cross-pin up, then drive out sight pin).
2. Remove ejector screw.
3. Place base over receiver and line up holes.
4. Insert attachment pin through base and gun's sight.
5. Retain with clips.
6. Fasten with new ejector screw with washer under head.
7. Install scope or other device per manufacturer's instructions.

NOTE: Some guns require a longer ejection than others. Use the ejector screw that fits your gun properly.

NOTE: Due to minor differences in guns, it may be necessary to file off radius on mount to allow ejector screw to line up.

SM-8565

Installation Instructions

BRITISH SMLE MKIII No.1 .303 Cal. SCOPE MOUNT

BE SURE GUN IS NOT LOADED

- 1) Place base against side of gun.
- 2) Install ejector screw with spring washer under head.
- 3) LEAVE LOOSE – DO NOT TIGHTEN.
- 4) Tighten adjust screw against gun's side until base is vertical and dovetail is horizontal.
- 5) Install Clamp bushing with screw and clamp base against gun's side.
- 6) Tighten ejector screw.
- 7) Install scope, etc. per manufacturer's instructions.

NOTE: Some guns require a longer ejection than others. Use the ejector screw that fits your gun properly.