



The FLEXIT SOLAR is the best option for emergency preparedness due to its renewable power source, complete flexibility, and overall brightness.

The FLEXIT SOLAR has a dual charging feature including solar and USB. Mother nature will charge the powerful lithium-ion battery in the FLEXIT for most occasions, and the micro-USB port is always available if the FLEXIT needs a quick charge at night.

The powerful center spot light is surrounded by 12 wide-angle flood LEDs. When you bend the FLEXiT into your desired shape, it can focus light on any object, or flood entire room! Use the independent power and mode buttons to access 5 lighting modes including red LED's to preserve "night-vision", and a rapid flashing hazard beacon that will immediately warn others of the your location

SPECIFICATIONS

Model # 00346 500 Lumens Integrated Li-ion Battery Dual Charge Options: Solar Panel or Micro-USB

FFATURES

Rechargeable
Ultra-thin Flexible Body
Center CREE LED Spot Light
Outer White Flood LEDs
Inner Red Night Vision LEDs

Dual charging via Micro-USB or

Solar Panel

5 Modes: High Spot & Flood / High Flood / Low Flood / Red Night Vision

/ Strobe

A SAFETY

- WARNING: This product contains high intensity LED devices. To prevent permanent eye damage, do not stare into the light beam at close range.
- To prevent battery damage use power charger with output of 1A to 2A to charge the Flexit Solar



QUESTIONS? Before returning to your retailer, call our customer service department at 704-508-1031, 8 a.m. - 5 p.m. ET, Monday - Friday or email us at info@STKRconcepts.com



Included: (1x) FLEXiT Solar, (1x) Instructions 1 Year warranty

Troutman, NC | 704-508-1031 | info@STKRconcepts.com | www.STKRconcepts.com




OPERATION

TURNING ON/OFF

Press power button located on top of main body to turn light on or off

Changing Modes

When FLEXiT is on press the "MODE" button to cycle through the 5 modes: High Spot & Flood > High Flood > Low Flood > Red Night Vision > Strobe



CHARGING

MICRO-USB

1) Lift up "USB" cover and plug a micro-USB cable into the micro-USB port of the FLEXIT SOLAR 2) plug the other end of the cable into a USB wall charger*, USB car charger*, or any other USB charging device* (such as a computer). *Not included. *Charger output of 1A to 2A is recommended to charge the FLEXIT Solar. To prevent battery damage charger output should NOT exceed 2A.

- - Power button blinks while charging then solid glow when fully charged.

SOLAR

Whenever the solar panel located on top of the main body of the FLEXIT SOLAR is exposed to light the battery will recharge. Charge time will vary greatly depending on available light.

**Please recharge a stored unit every four months to maintain optimum performance of the lithium-ion battery and maximize charging levels. Damage to unmaintained battery is not covered by warranty.



DESIGNED IN THE U.S.A PATENTED

Troutman, NC | 704-508-1031 | info@STKRconcepts.com | www.STKRconcepts.com