



INSTALLATION

1

- Ensure light switch is OFF
- Screw MPI Light into lamp holder

2

- Plug in all Pod lights. Feel for ROUND parts and stick plugs into ports

Do not plug lights into USB port

X4

3

- Let all four Pods hang

CAUTION: Be careful not to let the Pods fall to the ground

4

- Position the first light in the desired area.
- Position ladder in that location
- Go up ladder with Pod. Be careful
- Find exact desired location on ceiling

RECOMMENDED: Position Pod minimum 3 feet from surrounding wall.

Max length from hub is 9.5 feet

5

- Unscrew the ceiling plate counter-clockwise from the Pod
- Place plate on ceiling and mark holes

(5a) FINISHED CEILING:
• Drill hole using 3/16 (5mm) drill bit
• Insert supplied anchors into hole
• If you hit a joists don't use anchors

(5b) JOISTS:
• Position plate and screw screws directly into joists.
Do not use anchors

OTHER MOUNTING LOCATIONS
Use discretion to mount to other surfaces such as shelving, grid rack etc

WARNING: A poorly mounted light could fall, causing damage to car/object/person. Mount securely or hire a professional. STKR is not responsible for improper installation



INSTALLATION



6

- Position plate and drive screws into drywall anchors or joists
- Lightly seat screws with a screw driver or drill.

Do not overtighten

Ensure tabs are facing down

8

- Tighten cable by rotating Pod counter-clockwise

DO NOT OVERTIGHTEN CABLE:
Don't put undue pressure on main unit or light socket

REPEAT 4-8 For additional Pods. Make sure not to cross Pod cables.

2 HOUR MOTION SENSOR OVERRIDE

- With the Motion Sensor ON and Light ON
- Turn the light switch OFF (light pause), ON (light pause), OFF (light pause), ON within 5 seconds
- Lights stay on for 2 hours (disables motion sensor)
- After 2 hours the motion sensor functions as normal



7

ATTACH POD:
• Position Pod light over ceiling plate and rotate clockwise, until locked in place.

TO REMOVE POD:
• Press firmly up on the Pod
• Rotate counter-clockwise

ADJUSTING MOTION SENSOR

Set motion sensor to desired sensitivity or leave off if using like a light bulb.

OFF: Use the light switch to turn light on/off

LOW-MAX: Twist clockwise to increase the sensitivity of the motion sensor.

POWERING EXTERNAL CAMERA

- Turn light off at the light switch
- Plug USB plug from camera* into USB port of Main Hub
- Turn light on

*not incl.

IF LIGHT SWITCH IS OFF CAMERA WILL NOT HAVE POWER
To maintain constant power to camera, the light switch must remain in the ON position & motion sensor ON



SPECIFICATIONS

Model # 00194
Electrical Specifications: 100-240V, 50/60 Hz, 0.52A, 60 W
Base: Medium Screw (E26)
Environment: Indoor use only, dry location
Not Dimmable
Light Output:
7500 Lumens Total, 5400K color temperature
Motion Sensor:
Adjustable 360° motion detection
Motion Sensor Modes: Off, Min-Max sensitivity
Motion Sensor Timer: 2 min
USB Port Output: 5V 1.2A

Hub Dimensions:
7.6" x 7.5" x 4.25" (193mm x 191mm x 108mm)
Weight: 1.1 lb (500g)
Pod Dimensions:
4.1" x 3.9" x 2" (103mm x 100mm x 51mm)
Weight: 0.44 lb (200g)



INTRODUCTION

Unlike a traditional light fixture which has a single point of illumination, the MPI creates five points of light, all from your existing light fixture! These 5 points spread light to all corners of the room, filling the entire space and reducing shadows caused by single point illumination. This system installs in minutes and is powered by a standard light socket, eliminating the need to hire an electrician to properly light large spaces like a garage, attic, or basement.

INSTRUCTIONS

IMPORTANT

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is a safety alert symbol. This symbol alerts you to potential hazards that can hurt you and others.

PARTS (included)

1x Main Hub Light 4x Pod Lights 4x Ceiling Plates 8x Screws 8x Anchors



TOOLS

Required: Drill, Screw Driver, Pen/Pencil, Ladder



QUESTIONS? Before returning to your retailer, call our customer service department at 704-508-1031, Monday - Friday 8 a.m. - 5 p.m. ET, or email us at info@STKRconcepts.com

CHECK OUT MORE COOL STUFF AT
STKRCONCEPTS.COM



TRILIGHT SHOPLIGHT



MOBILE TASK LIGHT



GARAGE PARKING SENSOR



FLEXIT LIGHT



LIGHT MINE PRO



B.A.M.F.F.



ILLUMIDOME



FLEXIT HEADLAMP

LOVING YOUR NEW STKR PRODUCT?



Let the world know how much you love your new light on your favorite retail website, Google, @STKRconcepts or STKRconcepts.com

NOT SO HAPPY?

We want to hear from you. Let our world class customer service team take care of you.
CALL 704-508-1031 or EMAIL info@STKRconcepts.com

WARRANTY

1 Year manufacturers warranty
For warranty claims email warranty@STKRconcepts.com or call 704-508-1031



STKR CONCEPTS

STKRconcepts.com
Troutman, NC
1-704-508-1031
info@STKRconcepts.com