SIZING

S

L

XL

XXL

A

B

7.5" - 7.75"

3.5" - 3.75"

7.75" - 8"

3.75" - 4"

M

8" - 8.25"

8.5" - 8.75"

4" - 4.25"

4.25" - 4.5"

8.25" - 8.5"

4.5" - 4.75"

GLOVE PALM LENGTH

MEASURE FROM THE TIP OF THE FINGER JUST PAST THE CREASE OF YOUR WRIST В **GLOVE PALM WIDTH**

> MEASURE THE WIDTH WHERE YOUR PALM CREASES

