



X.C. SERIES HYDRATION PACKS

TOKUL™ / W's B-LINE™



OFFERING THE NEW BIG ZIP™ EVO RESERVOIR & COOL-RIDING RIDGEAIR™ BACK PANEL

X.C. low-profile hydration packs are built to deliver comfort while carrying the essentials on anything from quick laps to full-day hauls. These packs feature the upgraded Big Zip™ EVO reservoir delivering 3 liters of fast-flowing, taste-free hydration and the RidgeAir™ back

panel with ridged foam, cooling air channels and breathable mesh. The fold-open design offers simple organization options for tools and quick access for trailside repairs.



TOKUL™ X.C.

SIZE	5.0 L	8.0 L	12.0 L
GEAR STORAGE	2 liters	5 liters	9 liters
RESERVOIR CAPACITY	3L / 100 fl oz Big Zip™ EVO Hydration	3L / 100 fl oz Big Zip™ EVO Hydration	3L / 100 fl oz Big Zip™ EVO Hydration
TOTAL WEIGHT	1 lb 6 oz / 631 g	1 lb 8 oz / 704 g	1 lb 9 oz / 714 g
RESERVOIR WEIGHT	6.5 oz / 184 g	6.5 oz / 184 g	6.5 oz / 184 g

B-LINE™ X.C.

SIZE	8.0 L	12.0 L
GEAR STORAGE	5 liters	9 liters
RESERVOIR CAPACITY	3L / 100 fl oz Big Zip™ EVO Hydration	3L / 100 fl oz Big Zip™ EVO Hydration
TOTAL WEIGHT	1 lb 6 oz / 701 g	1 lb 7 oz / 711 g
RESERVOIR WEIGHT	6.5 oz / 184 g	6.5 oz / 184 g

FEATURE OVERVIEW

TOKUL™ / W's B-LINE™



A **NEW** Big Zip™ EVO premium hydration system delivers fast-flowing, taste-free water on the go

B Magnetic tube retention offers clip-free access to the bite valve

C Hydration storage pocket with hook and loop attachment keeps reservoir secure and easy to access

D RidgeAir™ back panel delivers lightweight, cooling ventilation

E Internal organization pockets sort and secure your gear

F Strap management keeps loose ends secure

G Long-track sternum strap adjustment provides a tailored, secure fit

H Reflective hits enhance visibility in low light

I Light attachment point secures a rear blinker

J Carry pocket stows a standard cross-country helmet (on Tokul X.C. 5.0, helmet can be attached with the pack's two webbing straps; included)

K Lightweight webbing waist belt stabilizes the pack for comfortable carrying

B-LINE ONLY FEATURES (NOT PICTURED):

Women's Fit offers female-tailored suspension design for optimal comfort

SoftTouch materials at contact points provide next-to-skin comfort

Waist belt pockets stow essentials for fast access

FEATURE DETAILS

TOKUL™ / W's B-LINE™



RIDGEAIR™ BACK PANEL

Lightweight, breathable mesh is backed by ridged foam with ventilation channels, enabling air to move efficiently across your back while you ride.



TOOL ORGANIZATION & SEPARATE PUMP SLEEVES

Zip mesh pocket with key clip, three mesh stash pockets, and two pump sleeves put bike tools, food, and keys within easy reach.



WAIST BELT POCKETS (B-LINE ONLY)

Two zippered pockets on the waist belt stow essentials like energy bars or gels for on-the-go access.



HELMET CARRY

Front stash pocket adjusts to fit a standard cross-country helmet for fast, easy access.



(Tokul X.C. 5.0 only: in place of a front stash pocket, two webbing straps attach helmet via the chinstrap)

HYDRATION FEATURES

BIG ZIP™ EVO / 3L



- A** Durable exterior with taste-free lining
- B** SlideLock™ to easily open, securely close and fill reservoir
- C** Pincher grip for easy one-handed filling
- D** Quick-disconnect mounted high for fast access
- E** Leakproof shut-off valve for reliable stowing

- F** Center baffle low-profile support and makes for easy cleaning & drying
- G** HyFLO™ self-sealing bite valve improves flow
- H** 5/16" tubing allows faster flow rates
- I** Embedded silver-ion protects clean water from mold & bacteria
- J** Pure materials are certified food-grade, BPA-, BPS-, and phthalate-free

INSTRUCTIONS

TUBE ROUTING

Preface: Shoulder and sternum strap adjustments should be determined before adjusting and routing the hydration tube, as pack fit adjustments affect the amount of hydration tube exposed.

QUICK-DISCONNECT

1. To disconnect the hydration tube from the reservoir, locate the quick-disconnect port at the top of the reservoir. Press the button at the port to release the hydration tube connector.



2. To reconnect the hydration tube, simply insert the quick-disconnect connector back into the port on the reservoir until it clicks.

ROUTE THE TUBE

1. Thread the bite valve and tube through the two webbing loops on the shoulder strap of your choosing. (Note: Routing the drink tube over the right shoulder is recommended, as it allows the bite valve to automatically return and reattach to the magnetic clip; however, the drink tube can be routed over the left strap, if desired.)
2. Locate the magnet clip attached to the tube and connect it to the magnet clip found on the shoulder strap.
3. Store any extra hydration tube length inside the pack in the hydration pocket, taking care to not kink the tube.
- 3A. Alternatively, you may cut the tube to a preferred length. (Note: When trimming the tube, do so from the bite valve end of the tube, removing the connector from the tube, trimming the tube to your preferred length, then replacing the connector.)




- 2A. For optimal performance, when routing the tube over the right shoulder, position the magnetic clip 3-4 inches (7.6–10.2 cm) from the bite valve.
- 2B. Alternatively, you can route the tube over the left shoulder strap, routing the tube across the chest and securing the bite valve on the right shoulder strap.
4. Put the pack on to verify desired location of bite valve and magnetic clip; adjust as necessary to optimize fit and bite valve location.
5. The magnetic tube clip provides easy access to hydration—when set up correctly, the magnets are designed to reattach hands-free after letting go of the bite valve.

INSTRUCTIONS

CONTINUED...

SHUT-OFF VALVE

1. The leak-proof shut-off valve, which connects the bite valve to the hydration tube, can be engaged and disengaged with an easy twist of the lever.



- 1A. To start water flow, twist the lever to line up with the water droplet icon.
- 1B. To stop water flow, twist the lever away from the bite valve to line up with the tubing.

SLIDELOCK™ CLOSURE

1. The SlideLock™ closure slides both ways across the top of the Big Zip™ EVO reservoir to ensure a leak-proof seal of the zippered opening.
2. To open the reservoir, slide the SlideLock toward either end until it is all the way off. The attached lanyard ensures it won't be dropped or lost.



3. Use the pincher grip to open the reservoir for one-handed filling by pinching the arrows together with one hand and turning on/off faucet with the other.



4. To close the reservoir, simply slide the SlideLock device back across the top of the reservoir until it stops.

MORE INFO

PLATYPUS CARE

HYDRATION PACK CARE

To get the best performance from your Platypus pack, follow these basic guidelines:

- Keeping your pack clean will help extend the life of your pack.
- Brush off superficial dirt, or rinse with warm water.
- If necessary, you can hand wash your pack with a sponge and mild soap. Rinse thoroughly to remove soap residue and hang dry.
DO NOT MACHINE WASH OR TUMBLE DRY YOUR PACK.
- Always empty and dry your pack before storage.

RESERVOIR CARE

To get the best performance from your Big Zip™ EVO, follow these basic guidelines:

- Rinse out your reservoir with warm water after each use.
- Always store your reservoir dry.
- Reservoirs are easy to dry on plastic drying racks, readily available at most kitchen supply retailers. Dry your reservoir zipper end up for maximum moisture evaporation. You can also dry with a clean dish towel due to the wide opening.
- Storing the reservoir in the freezer is also an option. If freezing with water inside, be aware water expands when it freezes and could damage your reservoir if overly full. Never store with water in your drink tube or shut-off valve.
- Never pour water that is hot to the touch into your reservoir as it can damage the lining.

MORE TIPS

For more tips and videos on the care and storage of your Platypus products, please visit us online at platy.com.

FOR WARRANTY SERVICE

Please contact our product service center at:

U.S. 1-800-531-9531

CANADA 1-888-801-5335

ONLINE platy.com/warranty

PLATYPUS

©2019 Cascade Designs, Inc.

4000 First Avenue South

Seattle, WA 98134 USA

1-800-531-9531

LIMITED LIFETIME WARRANTY | Details at: platy.com/warranty